
Wiring 12 input alarm module:



- As shown in above picture the right most terminal is +5V output.
- The second terminal after +5V is GND output
- The user inputs starts from the third terminal.
- User needs to either provide +5V to the inputs externally or short the input with +5V output via a switching mechanism as shown in above picture.
- Please note that the GND output on the board should be connected to the GND of any external DC electrical circuit that user is connecting this module to.

Programming the Alarm inputs:

The supplied software can be used to program the alarm inputs for the desired canned message and pager capcode/RIC code

If no message needed to transmit for HIGH or LOW position, simply leave the message box blank.

